

# Release Notes

## LANtools 10.80 RC1

### Table of contents

02	<b>1. Preface</b>
03	<b>2. New features, improvements, and history</b>
03	LANconfig 10.80.0008 RC1 / LANmonitor 10.80.0004 RC1
04	<b>3. Important advice</b>
04	Disclaimer

## 1. Preface

The LANtools are a comprehensive set of free management & monitoring tools for a detailed configuration and monitoring of LANCOM devices.

This document describes the innovations within LANtools version 10.80 RC1, as well as the improvements since the previous version.

### **Note**

LANCOM LANtools support Microsoft Windows 7, Windows 8, Windows 10, Windows 11, Windows 2008 Server, Windows Small Business Server 2011, Windows Server 2012, Windows Server 2012 R2, Windows Server 2016, and Windows Server 2019 (all 32- and 64-bit versions).

For Windows Vista and Windows 2008 Server you will find user data under \Users\USER\AppData\Roaming\LANCOM\ and the application files under \ProgramData\LANCOM\.

When upgrading to LANtools 8.50 or newer, all existing user- and application data is moved to the corresponding folders.

## 2. New features, improvements, and history

### **LANconfig 10.80.0008 RC1 / LANmonitor 10.80.0004 RC1**

#### **Bugfixes / improvements**

##### **LANconfig**

→ In the menu 'Interfaces / LAN / Ethernet Ports', all Ethernet ports on a LANCOM ISG-5000 in the default configuration were assigned the logical interface LAN-1 instead of the correct ascending assignment (ETH1 - LAN-1, ETH2 - LAN-2, etc.).

### 3. Important advice

#### **Disclaimer**

LANCOM Systems GmbH does not take any guarantee and liability for software not developed, manufactured or distributed by LANCOM Systems GmbH, especially not for shareware and other extraneous software.