Information regarding

LANtools Version 6.06

for LANCOM Routers and Wireless LAN Access-Points

Table of contents

1.   Introduction

The LANtools, consisting of LANconfig and LANmonitor, serve for the administration of all Wireless LAN Access Points and Routers. The at a time latest versions are available for all LANCOM products. You can download it for free at http://www.lancom-systems.com

This document describes the innovations within version 6.06 as well as the modifications since version 5.20.

Note

LANtools up to version 6.0x do still support the older Microsoft operating systems Windows95, Windows 98 and Windows NT 4.0. Subsequent LANtools versions will only support Windows 98 SE, Windows 2000, Windows XP and Windows 2003 Server.

2.   New Features, Modifications and History

LANconfig modifications from 6.04.0005 -> 6.06.0003
LANmonitor modifications from 6.02.0001 -> 6.06.0002

Corrections/Modifications:

LANconfig:

-        Support for spanish providers in the Internet Setup Wizard

LANmonitor:

-        For access points with two internal WLAN interfaces it is now possible to monitor both interfaces

LANconfig modifications from 6.02.0002 -> 6.04.0005

Corrections/Modifications:

LANconfig:

-        When printing the router configuration the application does not crash anymore.
-        When configuring ISDN-/SIP users it is now allowed to use spaces for the name to be displayed.
-        LANconfig does no longer ask for the DynamicVPN registration if the device is already registered.
-        The Internet-Wizard allows now using the user identification prefix for T-DSL Business with static IP adress.

LANconfig modifications from 6.00.0010 -> 6.02.0002
LANmonitor modifications from 6.00.0007 -> 6.02.0001

Corrections/Modifications:

LANconfig:

- An offline configuration for a 3x50 with activated UMTS option contains default values for UMTS.

LANconfig modifications from 5.20.0025 -> 6.00.0010
LANmonitor modifications from 5.20.0013 -> 6.00.0007

New Features:

LANconfig:

- Support for configuring the VoIP feature.
- New Setup Wizard for simple configuration of the VoIP feature.
- A failed configuration upload may be automatically retried.

LANmonitor:

- Status display of the VoIP Call Manager.

Corrections/Modifications:

LANmonitor:

- It is now permitted to use a „:" within the password.

WLANmonitor:

- Corrected sorting of IP addresses.